

ComfoWell CW 320 and CA 200

Installation sequence



1. CW-K 320 installation set
CA 200



2. Attach end plate to CA 200



3.



4. Place attenuator on the end
plate